

## Troubleshooting zit-sta bureau Flex Basic

<b>Loctek HAD troubleshooting guideline</b>		
<b>fault code</b>	<b>motor product</b>	<b>instruction</b>
E01	continuous working time too long	reuse after 13mins
E02	Over-temperature	over-temperature, reuse after 25mins
E03	motor1 over current	1.plz make sure loading weight not over rated range. if so,plz reduce loading weight. longpress"▼"down key to reset; 2. if not over weighted, plz reduce loading weight. longpress"▼"down key to reset
E05	motor1 lifting position fault	plz make sure if leg column is stuck. if not, plz longpress"▼"down key to reset
E07	motor1 HALL fault	plz check if motor wiring well with the control box, plug tight, then longpress"▼"down key to reset
E09	unbalanced table ends fault	plz check if table top ends unbalanced loading, if not, plz longpress"▼"down key to reset
E20	motor1 & two HALL fault	plz check if motor wiring well with the control box, plug tight, then longpress"▼"down key to reset
E22	motor1 & power supply & two HALL fault	same as above
E30	anti-collision fault	plz contact your supplier or dealer
_OL	glide fault	plz make sure loading weight not over rated range. if so,plz reduce loading weight. longpress"▼"down key to reset;